



## Wash Process Chart

<b>Laundry:</b>	JohnsonDiversey Lab
<b>City:</b>	Utrecht
<b>Contact:</b>	E. van Kouwen
<b>Date of visit:</b>	

<b>Classification Number:</b>					
<b>Classification:</b>	<b>Albatros Bluspakken</b>				
<b>Textile:</b>	Nomex				
<b>Machine:</b>	xx				
<b>Load factor &amp; Load [kg]:</b>	70% kg				
Step	Time [min]	Level	Temp [°C]	Product CLAX	Dosage [g/kg]
Prewash	7	L	30	Clax 100S 2BL1	5,0
Mainwash	12	L	60	Clax 100S 2BL1	7,0
				Clax Plus 3SL1	5,0
Drain	1				
Rinse 1	3	H	Cold	Clax Proof integral	3,0
Drain	1				
Rinse 2	3	H	Cold		
Drain	1				
Rinse 3	3	H	Cold		
Drain	1				
Final extraction	5	800			
<b>Total process time:</b>	<b>37</b>	<b>[min]</b>			
<b>Remarks:</b>	Drogen volgens voorschrift fabrikant				
	Doseringen zijn gebaseerd op een lage tot 7°DH waterhardheid				
Version: #REF!					

**Country:** JohnsonDiversey Netherlands